











































































	Original	Replacement		Original	Replacement
	Standby		Power		Right
	Rec PVR		Rec		Left
	PVR List		List		Ok
	Mute		Mute		Vol +
	EPG		Guide		Vol -
	Audio		Dual		1
	Info		Info		2
	TTX		Text		3
	Subtitle		Subt		4
	Menu		Menu		5
	Exit		Exit		6
	Favourite		Pre Ch		7
	Tv/Radio		TV/R		8
	CH+		Ch +		9
	CH-		Ch -		0
	Up		Up		Recall
	Down		Down		Goto
					Back
					AV





	Original	Replacement	Original	Replacement
	<<			<<
	>>			>>
	<<			<<
	>>			>>
	Play			Play
	Pause			Pause
	Stop			Stop
	Repeat	 + 		Shift + Text
	Red			Red
	Green			Green
	Yellow			Yellow
	Blue			Blue

