





































Original	Replacement
	 Power
	 Menu
	 D. Menu
	 Exit
	 Back
	 Red
	 Green
	 Yellow
	 Blue
	 Ok
	 Up
	 Down
	 Right
	 Left
	 Mute
	 Vol +
	 Vol -

Original	Replacement
	 Ch +
	 Ch -
	 Info
	 Shift + Options
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 Pre Ch
	 TV/R
	 Text





Original		Replacement		Original	Replacement
	*/o..		Eject		
	Source/Game		AV		
	*/o		List		
	World		Guide		
	Music/Movie/Phot		Options		
	[-O-]		Sleep		
	[≡]..		Subt		
	Lang		Dual		
	Rec		Rec		
	Stop		Stop		
	Pause		Pause		
	Play		Play		
	>>		>>		
	<<		<<		

