





















































Original	Replacement	Original	Replacement
 Power	 Power	 -/--	 Shift + Guide
 Mute	 Mute	 TV Menu	 Menu
 Source	 AV	 DVB Menu	 D. Menu
 PMode	 Format	 D.Exit	 Exit
 SMode	 Shift + Dual	 QV	 Pre Ch
 I/II	 Dual	 Call	 Back
 Sleep	 Sleep	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 V-	 Vol -
 6	 6	 V+	 Vol +
 7	 7	 P-	 Ch -
 8	 8	 P+	 Ch +
 9	 9	 Red	 Red
 0	 0	 Green	 Green





Original		Replacement		Original	Replacement
	Yellow		Yellow		
	Blue		Blue		
	Subtitle		Subt		
	Size		3D		
	Hold		Stop		
	Reveal		Smart		
	TV / Text		Text		
	Index		Shift + Info		
	Cancel		Shift + Back		
	Mix		Shift + Text		
	Subpage		Shift + Subt		
	FAV		Shift + Pre Ch		
	Info		Info		
	Language		Options		
	TV / Radio		TV/R		
	EPG		Guide		

