







Original	Replacement
	 Power
	 AV / Input / RDS
	 Shift + Green / APP / Repeat
	 Shift + Yellow / YouTube / Repeat
	 Shift + Blue / Prime / Random
	 Shift + 4
	 Shift + 5
	 Shift + 6
	 Shift + 7
	 Shift + 8
	 Shift + 9
	 Shift + Red / Netflix / Search
	 Shift + 0
	 Fav / Marker / PC
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat

Original	Replacement
	 Blue / Prime Video / Random
	 D.Menu / Top
	 Play / Slow
	 Pause / Step / Freeze
	 Up
	 Left
	 OK
	 Right
	 Back / Return
	 Down
	 Exit / Cancel / Clear
	 Vol+
	 Menu / Home
	 CH+ / Page+
	 Vol-
	 Display / Media
	 CH- / Page-



