







































































Original	Replacement
 Power	 Power
 Sleep	 Sleep / Timer
 Screen	 Picture / Format
 Presets	 Setup / OPT /
 ↔	 TV/Radio /
 FAV	 Shift + Fav / Marker / PC
 Lang	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 TXT	 Text / Goto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8

Original	Replacement
 9	 9
 EPG	 Guide / EPG / -/-
 0	 0
 SWAP	 Fav / Marker / PC
	 D.Menu / Top
	 Smart / List
 SOURCE	 AV / Input / RDS
 MENU	 Menu / Home
	
	
 OK	 OK
	
	
 C	 Exit / Cancel / Clear
 DISP.	 Display / Media
	 Shift + Red / Netflix /
	 Back / Return





	Original	Replacement		Original	Replacement
	CH+	 CH+ / Page+		Yellow/Root	 Yellow / YouTube / Repeat
	Info	 Info / Angle		Blue/Title	 Blue / Prime Video / Random
	Vol+	 Vol+			
	CH-	 CH- / Page-			
	Mute	 Mute / Dimmer			
	Vol-	 Vol-			
	Rec	 Rec / Rec Mode			
	Pause	 Pause / Step / Freeze			
	I<<	 I<< / Preset-			
	>>I	 >>I / Preset+			
	<<	 << / Tune-			
	Play	 Play / Slow			
	Stop	 Stop / Hold			
	>>	 >> / Tune+			
	Red/↑/Zoom	 Red / Netflix / Search			
	Red/↑/Zoom	 Zoom / Size			
	Green/↓/Repeat	 Green / APP / Repeat			

