






























































Original		Replacement		Original		Replacement	
	Power		Power		Left		LEFT
	(o)		V-FOR		OK		OK
	♪		Audio		P+		CH +
	[AIB]		Shift + Audio		P-		CH -
	Input		SRC		Vol+		VOL +
	16:9		WIDE		Vol-		VOL -
	[=]		TEXT		1		1
	Mute		MUTE		2		2
	Red		Red (A)		3		3
	Green		Green (B)		4		4
	Yellow		Yellow (C)		5		5
	Blue		Blue (D)		6		6
	[■]		MENU		7		7
	X		EXIT		8		8
	Up		UP		9		9
	Down		DOWN		0		0
	Right		RIGHT		Recall		P/C / FAV





Original	Replacement	Original	Replacement
[I]	-/-- / EPG		
[=i]	INFO		
[...]	Subt.		
[]	OPT+		
[=?]/(↔)	TV/R		
I-II-▼/Lang	VOD		
[=x]/Timer	MEDIA		
[=♦]	BACK		
[=+]	SHIFT + Shift + Subt.		





Original		Replacement		Original		Replacement	
	Power		Power		3		3
	Input		SRC		4		4
	[M]		MENU		5		5
	Up		UP		6		6
	Down		DOWN		7		7
	Right		RIGHT		8		8
	Left		LEFT		9		9
	OK		OK		0		0
	P+		CH +		I-II-▼/Lang		Audio
	P-		CH -		[=◆]		BACK
	Play		Play				
	<<		Rewind				
	Pause		Pause				
	>>		Fast Forward				
	Stop		Stop				
	1		1				
	2		2				

