







































































































Original	Replacement	Original	Replacement
	Power		Power
	Input		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	[I/II]		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	I/II		Dual
	Mute		Mute
	PR+		Ch +
	PR-		Ch -
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Text		Text
	[≡x]		Options
	[...]		Subt
	Menu		Menu
	[≡?]		Sleep
	Return		Shift + Back
	[i+]		Info
	[> <]		Format
	Guide		Guide
	OK		Ok
	Up		Up





Original		Replacement		Original		Replacement	
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	>>		>>				
	<<		<<				
	I<<		I<<				
	>>I DVD		>>I				
	Power		Power				
	PR+		Ch +				
	PR-		Ch -				
	Menu		Menu				
	Up		Up				
	OK		Ok				
	Down		Down				
	Right		Right				
	Left		Left				



