







































































| Original | Replacement |
|---|---|
|  Power |  Power |
|  Info |  Info / Angle |
|  Sleep |  Sleep / Timer |
|  Tv/R |  TV/Radio / |
|  AUX |  Shift + 7 |
|  EPG |  Guide / EPG / -/-- |
|  Audio |  Audio / Lang I/II |
|  Red/Text |  Shift + Red / Netflix / |
|  Green/Recall |  Shift + Green / APP / |
|  Yellow/Games |  Shift + Yellow / YouTube / |
|  Blue/Audio |  Blue / Prime Video / Random |
|  Exit |  Exit / Cancel / Clear |
|  Menu |  Menu / Home |
|  FAV >> |  >> / Tune+ |
|  << FAV |  << / Tune- |
|  Up |  Up |
|  OK |  OK |

| Original | Replacement |
|---|---|
|  Down |  Down |
|  Right |  Right |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  Left |  Left |
|  Pause |  Pause / Step / Freeze |
|  Mute |  Mute / Dimmer |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |



