







































































Original	Replacement	Original	Replacement
 Power	 Power	 Mute	 Mute
 Source	 AV	 P+	 Ch +
 1	 1	 P-	 Ch -
 2	 2	 Menu	 Menu
 3	 3	 Q.Menu	 D. Menu
 4	 4	 Back	 Back
 5	 5	 Exit	 Exit
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 OK	 Ok
 [TV]	 TV/R	 i	 Info
 ↔	 Pre Ch	 [>]	 Options
 Internet	 Smart	 EPG	 Guide
 Vol+	 Vol +	 *1	 Format
 Vol-	 Vol -	 *2	 3D





Original	Replacement	Original	Replacement
 TXT	 Text		
 Lang.	 Dual		
 Subt.	 Subt		
 [+]	 Eject		
 <<<	 <<<		
 Pause	 Pause		
 >>>	 >>>		
 Rec	 Rec		
 Play	 Play		
 Stop	 Stop		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

