



| Original   | Replacement   |
|--|---|
|  Power    |  Power             |
|  Mute     |  Mute              |
|  1        |  1                 |
|  2        |  2                 |
|  3        |  3                 |
|  4        |  4                 |
|  5        |  5                 |
|  6        |  6                 |
|  7        |  7                 |
|  8        |  8                 |
|  9       |  9                |
|  0      |  0               |
|  FAV    |  Shift + Pre Ch |
|  Recall |  Pre Ch         |
|  Game   |  Media          |
|  Auto   |  Smart          |
|  Info   |  Info           |

| Original  | Replacement  |
|---|--|
|  Menu                |  Menu     |
|  EPG                 |  Guide    |
|  Exit                |  Exit     |
|  Up / CH + / I<<     |  Up       |
|  Down / CH - / >>I   |  Down     |
|  Right / Vol +       |  Right    |
|  Left / Vol -        |  Left     |
|  OK                  |  Ok       |
|  Up / CH + / I<<     |  I<<      |
|  Down / CH - / >>I   |  >>I      |
|  Up / CH + / I<<    |  Ch +    |
|  Down / CH - / >>I |  Ch -   |
|  Left / Vol -      |  Vol -  |
|  Right / Vol +     |  Vol +  |
|  Red / Zoom        |  Red    |
|  Green / Lan/Audio |  Green  |
|  Yellow /          |  Yellow |



Play/Pause

