







































































Original		Replacement		Original		Replacement	
	Power		Power		Down		Down
	Mute		Mute / Dimmer		Exit		Exit / Cancel / Clear
	Picture		Picture / Format		1		1
	Sound		Sound / Title		2		2
	Aspect		Shift + Picture / Format		3		3
	Sleep		Sleep / Timer		4		4
	Subtitle		Subtitle / EQ		5		5
	CH. List		Smart / List		6		6
	EPG		Guide / EPG / -/--		7		7
	FAV		Fav / Marker / PC		8		8
	TV / Radio		TV/Radio /		9		9
	Up		Up		0		0
	Input		AV / Input / RDS		Recall		Back / Return
	Left		Left		Info		Info / Angle
	OK		OK		Vol +		Vol+
	Right		Right		Rec		Rec / Rec Mode
	Menu		Menu / Home		Rec. List		Display / Media





	Original	Replacement	Original	Replacement
	CH +	 CH+ / Page+		>>I / Subpage
	Vol -	 Vol-		
	Play / Pause	 Play / Slow		
	Play / Pause	 Pause / Step / Freeze		
	Stop	 Stop / Hold		
	CH -	 CH- / Page-		
	Red	 Red / Netflix / Search		
	Green	 Green / APP / Repeat		
	Yellow	 Yellow / YouTube / Repeat		
	Blue	 Blue / Prime Video / Random		
	TV / TXT	 Text / Goto		
	Cancel	 Shift + Exit / Cancel / Clear		
	Reveal	 Eject / Surround		
	Nicam / A2	 Audio / Lang I/II		
	<< / Index	 << / Tune-		
	>> / Hold	 >> / Tune+		
	I<< / Size	 I<< / Preset-		

