Original		Replacement	
	Power		Power
	V- Format	PICTURE FORMAT	Format
	Mute	MUTE	Mute
SAT	F1	SHIFT + 1	Shift + 1
	F2	SHIFT + 2	Shift + 2
TV/AV	TV/ AV	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
FAV	Fav	FAV PRE-CH	Pre Ch
PAUSE	Pause		Pause
	Page+	SHIFT + CH +	Shift + Ch +
	Page-	SHIFT + CH −	Shift + Ch -
←PR	←PR	RETURN BACK	Back
PR+	Up / PR+	CH +	Ch +
PR+	Up / PR+		Up
PR-	Down / PR-	CH −	Ch -
PR-	Down / PR-		Down
	Right / Vol +	VOL +	Vol +
	Right / Vol +		Right
	Left / Vol -	VOL −	Vol -
	Left / Vol -		Left
OK LIST	OK / List	OK	Ok
OK LIST	OK / List	DISC NAV LIST	List
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit

Original		Replacement	
	Info	DISPLAY INFO	Info
	EPG	-/-- GUIDE	Guide
	Red / Find	A	Red
	TV/Radio	SEARCH TV/R	TV/R
	Red / Find	SHIFT + SEARCH TV/R	Shift + TV/R
	Green / TXT	B	Green
	Green / TXT	REPEAT TEXT	Text
	Yellow / Subtitl	C	Yellow
	Yellow / Subtitl	AD SUBT	Subt
	Blue / Audio	D	Blue
	Blue / Audio	SOUND DUAL	Dual
	Record	REC MODE	Rec
	Play	PLAY MODE	Play
	Stop		Stop
	Shift	HOME SMART	Smart
	<< Fast	<<	<<
	Fast >>	>>	>>

Original		Replacement	
	< Slow		I <<
	Slow >		>>I

Original		Replacement	
	Power		Power
	V-Format		Format
	Mute		Mute
	F1	SHIFT + 1	Shift + 1
	F2	SHIFT + 2	Shift + 2
	TV/AV		AV
	Sleep		Sleep
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0

Original		Replacement	
	Fav		Pre Ch
	Pause		Pause
	Page+	SHIFT + CH+	Shift + Ch +
	Page-	SHIFT + CH-	Shift + Ch -
	←PR		Back
	Up / PR+		Ch +
	Up / PR+		Up
	Down / PR-		Ch -
	Down / PR-		Down
	Right / Vol +		Vol +
	Right / Vol +		Right
	Left / Vol -		Vol -
	Left / Vol -		Left
	OK / List		Ok
	OK / List		List
	Menu		Menu
	Exit		Exit

Original		Replacement		Original		Replacement	
INFO	Info	DISPLAY INFO	Info	SLO	< Slow	⏮	I <<
EPG	EPG	-/-- GUIDE	Guide	SLOW	Slow >	⏭	>>I
FIND	Red / Find	A	Red				
TV/RADIO	TV/Radio	SEARCH TV/R	TV/R				
	Red / Find	SHIFT +	SEARCH TV/R Shift + TV/R				
	Green / TXT	B	Green				
	Green / TXT	REPEAT TEXT	Text				
	Yellow / Subtitl	C	Yellow				
	Yellow / Subtitl	AD SUBT	Subt				
	Blue / Audio	D	Blue				
	Blue / Audio	SOUND DUAL	Dual				
	Record	REC MODE	Rec				
	Play	PLAY MODE ▶	Play				
	Stop	■	Stop				
SHIFT	Shift	HOME SMART	Smart				
FAS	<< Fast	⏪	<<				
AST	Fast >>	⏩	>>				