




































































































Original	Replacement	Original	Replacement
Lang./Rewind	 << / Tune-	7pqrm	 7
	 +  Shift + Right	8tuv	 8
	 +  Shift + Left	9wxyz	 9
+	 +  Shift + CH+ /	Guide Pilote	 Guide / EPG / -/--
Sys/Serv	 Sound / Title	0/10	 0
Interat	 Picture / Format	FAV Pref.	 Fav / Marker / PC
Pers.	 D.Menu / Top	Red	 Red / Netflix / Search
TV	 TV/Radio /	Green	 Green / APP / Repeat
Browse	 Smart / List	Yellow	 Yellow / YouTube / Repeat
Lang./Rewind	 +  Shift + Audio / Lang I/II	Blue	 Blue / Prime Video / Random
Epg	 +  Shift + Guide / EPG / -/--	2abc	 2
TV/SAT	 AV / Input / RDS	Dev	 >> / Preset+
West	 << / Preset-	Freeze	 Pause / Step / Freeze
3def	 3	East	 Rec / Rec Mode
4ghi	 4	H/V Play	 Play / Slow
5jkl	 5	LNB F.Forward	 >> / Tune+
6mno	 6	Menu Up	 Up



Original	Replacement	Original	Replacement
Mute	 Mute / Dimmer	Back	 Back / Return
Opt?	 Setup / OPT /	Volume+	 Vol+
App	 +  Shift + Green / APP /	CH/Page+	 CH+ / Page+
Info	 Info / Angle	Volume-	 Vol-
Subt.List	 Subtitle / EQ	Audio	 Audio / Lang I/II
Sleep Timer	 Sleep / Timer	CH/Page-	 CH- / Page-
Video	 +  Shift + 4	1. ?	 1
Text	 Text / Goto		
Zoom	 Zoom / Size		
Menu	 Menu / Home		
PWR On/Off	 Power		
Display	 Display / Media		
Menu Left	 Left		
OK Enter	 OK		
Menu Right	 Right		
Exit	 Exit / Cancel / Clear		
Menu Down	 Down		



Original	Replacement	Original	Replacement
Blue / Timer	 Shift + Sleep / Timer	Info	 Info / Angle
Blue / Timer	 Blue / Prime Video / Random	EPG	 Guide / EPG / -/-
TV Mode	 Display / Media	FAV	 Fav / Marker / PC
Play/Pause	 Pause / Step / Freeze	Left	 Left
YouTube	 Shift + Yellow / YouTube /	Audio	 Audio / Lang I/II
Red / M/P	 Red / Netflix / Search	Subtitle	 Subtitle / EQ
Green / Video	 Green / APP / Repeat	Stop	 Stop / Hold
Yellow / PVR	 Yellow / YouTube / Repeat	Rec	 Rec / Rec Mode
PG-	 CH- / Page-	Play/Pause	 Play / Slow
Find	 Shift + Red / Netflix /	8	 8
PG+	 CH+ / Page+	Mute	 Mute / Dimmer
OK	 OK	Menu	 Menu / Home
Right	 Right	Exit	 Exit / Cancel / Clear
Down	 Down	1	 1
Recall	 Back / Return	2	 2
Sleep	 Sleep / Timer	3	 3
TV / Rad	 TV/Radio /	4	 4



