






























Original	Replacement
	Power
	CD
	Tuner
	Aux
	Tape/Monitor
	DVD
	Video
	VCR1
	VCR2
	Seek-
	Seek+
	Preset-
	Preset+
	FM
	AM
	Surround Off
	Dolby Digital

Original	Replacement
	Pro Logic
	DTS
	Natural
	Hall
	M Range
	LFE Att.
	Display
	Mute
	Volume+
	Volume-
	Speaker Select
	Speaker Mode
	Balance

