



Original	Replacement
 Power	 Power
 Source	 AV
 Rec	 Rec
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 Lang	 Dual
 <<<	 <<<
 >>>	 >>>
 [≡]..	 Subt
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 1	 1
 2	 2
 3	 3

Original	Replacement
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Tv	 TV/R
 Recall	 Pre Ch
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Menu	 Menu
 Back	 Back
 Exit	 Exit



