



Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute / Dimmer
	Pause		Pause / Step / Freeze
	White/Fav Down		<< / Tune-
	FAV Up		>> / Tune+
	Audio		Audio / Lang I/II
	Tv/Radio		TV/Radio /
	Text		Text / Goto
	Menu		Menu / Home
	Up		Up
	Info		Info / Angle
	Left		Left
	OK		OK
	Right		Right
	Exit		Exit / Cancel / Clear
	Down		Down
	Recall		Back / Return
	Vol+		Vol+
	UHF		Smart / List
	CH+		CH+ / Page+
	Vol-		Vol-
	SAT/TV		Display / Media
	CH-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8/Lang		8
	9		9
	EPG		Guide / EPG / -/-
	0		0





Original	Replacement
	Fav / Marker / PC
	Red / Netflix / Search
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	+ 0 Shift + 0

Original	Replacement

