












































Original	Replacement	Original	Replacement
 Power	 Power	 Up	 Up
 Mute	 Mute	 Down	 Down
 1	 1	 Right	 Right
 2	 2	 Left	 Left
 3	 3	 Atrás	 Back
 4	 4	 Salir	 Exit
 5	 5	 abc/Borrar	 Options
 6	 6	 VOD/Videoclub	 Smart
 7	 7	 Familiar	 Subt
 8	 8	 Multimedia	 Media
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 Info	 Info	 Prog+	 Ch +
 Guia	 Guide	 Prog-	 Ch -
 ver Tv	 TV/R	 X/Zoom	 3D
 Favoritos	 Pre Ch	 Rec	 Rec
 Menu	 Menu	 Play	 Play





Original		Replacement		Original		Replacement	
	Pause		Pause				
	Stop		Stop				
	>>		>>				
	<<		<<				
	I<<		I<<				
	>>I		>>I				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	OK		Ok				
	Q..		Dual				

