





















































































Original	Replacement	Original	Replacement
 Power	 Power	 i	 DISPLAY INFO Info
 AV	 TIMER AV AV	 + P	 + CH Ch +
 1 ./@	 1	 - P	 - CH Ch -
 2 abc	 2	 MENU	 TOP MENU MENU Menu
 3 def	 3	 EXIT	 CLEAR EXIT Exit
 4 ghi	 4	 OPTION	 SETTINGS OPT Options
 5 jkl	 5	 BACK/RETURN	 RETURN BACK Back
 6 mno	 6		
 7 pqrs	 7		
 8 tuv	 8		
 9 wxyz	 9		
 0 _	 0	 OK	 OK Ok
 STILL	 PICTURE FORMAT Format	 TV	 SEARCH TV/R TV/R
	 FAV PRE-CH Pre Ch	 MEDIA	 APP MEDIA Media
 + Vol+	 + VOL Vol +	 GUIDE	 - / - GUIDE Guide
 - Vol-	 VOL Vol -		 ECO 3D 3D
 Mute	 MUTE Mute	 TIMER	 SHIFT + TIMER AV Shift + AV





Original		Replacement		Original		Replacement	
	Text		Text				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Audio		Dual				
	STTL		Subt				
	Sound		Shift + Dual				
	<<		<<				
	Pause		Pause				
	>>		>>				
	Rec		Rec				
	Play		Play				
	Stop		Stop				

