




Original	Replacement	Original	Replacement
	Power		Red
	TXT		Green
	EPG		Yellow
	Input		Blue
	Menu		Vol +
	[>]		Vol -
	Lang		Mute
	Subt		[+]
	Subt		Ch +
	i		Ch -
	Exit		1
	Q.Menu		2
	Back		3
	Up		4
	Down		5
	Right		6
	Left		7
	OK		



