





















































































Original	Replacement
	 AV / Input / RDS
	 Power
	 Shift + 4
	 Shift + 2
	 Shift + 5
	 Shift + 7
	 Picture / Format
	 Shift + Zoom /
	 Subtitle / EQ
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 >> / Tune+
	 Guide / EPG / -/--
	 Up
	 Text / Goto

Original	Replacement
	 Left
	 Right
	 OK
	 Down
	 Menu / Home
	 Vol+
	 CH+ / Page+
	 Vol-
	 Mute / Dimmer
	 CH- / Page-
	 1
	 2
	 3
	 4
	 5
	 6
	 7








































































	Original	Replacement	Original	Replacement
	8	 8		
	9	 9		
	[i+]	 Info / Angle		
	0	 0		
	P<P	 Fav / Marker / PC		
	♪ Smart	 Sound / Title		
	[-o-]/Active Control	 D.Menu / Top		
	[ ] Smart	 Smart / List		
	[o]	 TV/Radio /		
	Setup	 Setup / OPT /		
	[+]	 Display / Media		
	[♦]/Zoom	 Zoom / Size		
	[ ]	 Audio / Lang I/II		
	Instant	 Back / Return		
	[<>]	 Sleep / Timer		
	[↔]	 Eject / Surround		








Original	Replacement
	 AV / Input / RDS
	 Power
	 Shift + 4
	 Shift + 2
	 Shift + 5
	 Shift + 7
	 Zoom / Size
	 Subtitle / EQ
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 >> / Tune+
	 Guide / EPG / -/-
	 Up
	 Text / Goto
	 Left



































Original	Replacement
	 Right
	 OK
	 Down
	 Menu / Home
	 Vol+
	 CH+ / Page+
	 Vol-
	 Mute / Dimmer
	 CH- / Page-
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8










































Original	Replacement
	 AV / Input / RDS
	 Power
	 Shift + 4
	 Shift + 2
	 Shift + 5
	 Shift + 7
	 Zoom / Size
	 Subtitle / EQ
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat
	 Blue / Prime Video / Random
	 >> / Tune+
	 Guide / EPG / -/-
	 Up
	 Text / Goto
	 Left



































































Original	Replacement
	 Right
	 OK
	 Down
	 Menu / Home
	 Vol+
	 CH+ / Page+
	 Vol-
	 Mute / Dimmer
	 CH- / Page-
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8









Original	Replacement	Original	Replacement
	 AV / Input / RDS		 Vol+
	 Power		 CH+ / Page+
	 Shift + 4		 Vol-
	 Shift + 2		 Mute / Dimmer
	 Shift + 5		 CH- / Page-
	 Shift + 7		 1
	 Subtitle / EQ		 2
	 Green / APP / Repeat		 3
	 >> / Tune+		 4
	 Guide / EPG / -/--		 5
	 Up		 6
	 Text / Goto		 7
	 Left		 8
	 Right		 9
	 OK		 0
	 Down		 Fav / Marker / PC
	 Menu / Home		

