


















































































Original	Replacement	Original	Replacement
	Power		Power
	Sleep		Sleep
	Mute		Mute
	Mode		Smart
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Nicam/A2		Dual
	TXT / Mix		Text
	TV / Radio		TV/R
	List		List
	Back		Back
	Menu		Menu
	CH +		Ch +
	CH -		Ch -
	Vol +		Vol +
	Vol -		Vol -
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	FAV		Pre Ch
	EPG		Guide
	Info		Info
	Exit		Exit
	Red		Red





Original	Replacement	Original	Replacement
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Hold	 Stop		
 Index	 Media		
 Size	 Eject		
 Reveal	 3D		
 Subtitle	 Subt		
 Subpage	 Shift + Subt		
 Picture	 Format		
 Sound	 Shift + Dual		

Original	Replacement

