



	Original	Replacement		Original	Replacement
	Power		Power		Aspect
	Auto		Smart		Nicam
	Mute		Mute		Display
	1		1		CH +
	2		2		CH -
	3		3		Up
	4		4		Right
	5		5		Down
	6		6		Left
	7		7		Enter
	8		8		Menu
	9		9		Exit
	0		0		Input
	-/--		Guide		P.Mode
	Recall		Pre Ch		S.Mode
	Vol +		Vol +		Sleep
	Vol -		Vol -		Text
					Format
					Dual
					Info
					Ch +
					Ch -
					Up
					Right
					Down
					Left
					Ok
					Menu
					Exit
					AV
					Shift + Format
					Shift + Dual
					Sleep
					Text





Original		Replacement		Original		Replacement	
	Hold		Pause				
	PGUP		Shift + Up				
	PGDW		Shift + Down				
	Index		Shift + Info				
	Size		Eject				
	Reveal		Media				
	Subpage		Subt				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Cyan		Blue				

