



| Original | Replacement |
|-----------|------------------|
| Power TV | Power |
| Power STB | + Shift + Power |
| Source | AV |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| 0 | 0 |
| TTX/MIX | Text |
| PRE-CH | Pre Ch |
| Vol+ | Vol + |
| Vol- | Vol - |

| Original | Replacement |
|-------------|-------------|
| Mute | Mute |
| CH.List | List |
| P+ | Ch + |
| P- | Ch - |
| Menu | Menu |
| Smart Hub | Smart |
| Guide | Guide |
| Tools | Options |
| Info | Info |
| Back/Return | Back |
| Exit | Exit |
| Up | Up |
| Down | Down |
| Right | Right |
| Left | Left |
| OK | Ok |
| Red | Red |





| Original | | Replacement | | Original | Replacement |
|---|-----------|---|---------|----------|-------------|
|  | Green |  | Green | | |
|  | Yellow |  | Yellow | | |
|  | Blue |  | Blue | | |
|  | D |  | Dual | | |
|  | Status |  | TV/R | | |
|  | More |  | 3D | | |
|  | E-Manual |  | D. Menu | | |
|  | Recommend |  | Format | | |
|  | AD/Subt |  | Subt | | |
|  | << |  | << | | |
|  | I<< |  | I<< | | |
|  | Pause |  | Pause | | |
|  | >> |  | >> | | |
|  | >>I |  | >>I | | |
|  | Rec |  | Rec | | |
|  | Play |  | Play | | |
|  | Stop |  | Stop | | |

