







































































Original	Replacement	Original	Replacement
 Standby/On	 Power	 <<	 <<
 Open/Close	 Eject	 >>	 >>
 DVD	 Smart	 <<	 <<
 HDD	 Media	 Stop	 Stop
 USB	 Shift + Media	 Play	 Play
 Input Sel	 Subt	 Pause	 Pause
 1	 1	 >>	 >>
 2	 2	 Tv Vol+	 Vol +
 3	 3	 Tv Vol-	 Vol -
 4	 4	 Tv Mute	 Mute
 5	 5	 Audio	 Dual
 6	 6	 DTV/Analog	 Format
 7	 7	 Prog+	 Ch +
 8	 8	 Prog-	 Ch -
 9	 9	 Menu	 Menu
 0	 0	 Return	 Back
 Tv/DVD	 TV/R	 Up	 Up





Original	Replacement
Down	Down
Right	Right
Left	Left
OK	Ok
Title List/Disc Menu	List
Info	Info
Exit	Exit
Play List/Title Menu	D. Menu
Red/Subtitle	Red
Green/Rec	Green
Yellow/ALT	Yellow
Blue/FAV List	Blue
Guide	Guide
Marker/Tv/Radi	3D
Repeat/Timer	AV
Text	Text
Rec	Rec

Original	Replacement
Rec Pause/Time Shift	+ Shift + Pause





Original	Replacement	Original	Replacement
Tv Standby/On	Power		
Input Sel	AV		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
Tv Mute	Mute		
Tv Vol+	Vol +		
Tv Vol-	Vol -		
Prog+	Ch +		
Prog-	Ch -		

