











Original		Replacement		Original		Replacement	
	Power		Power		Tools		Options
	Source		AV		Mute		Mute
	[+]		D. Menu		Vol+		Vol +
	[> <]		Format		Vol-		Vol -
	A/B		Pre Ch		Prog+		Ch +
	EPG [I]		Shift + Options		Prog-		Ch -
	[i+]		Info		Text		Text
	Red		Red		Back		Back
	Green		Green		0		0
	Yellow		Yellow		1		1
	Blue		Blue		2		2
	Up		Up		3		3
	Down		Down		4		4
	Right		Right		5		5
	Left		Left		6		6
	Menu		Menu		7		7
	Return		Shift + Back		8		8





Original		Replacement		Original		Replacement	
	9		9				
	Digital		TV/R				
	Analog		List				
	OK		Ok				

