

































































Original	Replacement	Original	Replacement
 Source	 AV / Input / RDS	 Guide	 Guide / EPG / -/--
 Power	 Power	 Sync Menu	 D.Menu / Top
 TrackID	 Sound / Title	 Up	 Up
 I<<	 I<< / Preset-	 [i+]/[?]	 Info / Angle
 Pause	 Pause / Step / Freeze	 Left	 Left
 >>I	 >>I / Preset+	 OK	 OK
 ?/i-Manual	 TV/Radio /	 Right	 Right
 <<	 << / Tune-	 Return/Back	 Back / Return
 Play	 Play / Slow	 Down	 Down
 >>	 >> / Tune+	 Options	 Setup / OPT /
 Format	 Picture / Format	 Home	 Menu / Home
 Stop	 Stop / Hold	 Red	 Red / Netflix / Search
 Rec	 Rec / Rec Mode	 Green	 Green / APP / Repeat
 Digital/Analog	 Zoom / Size	 Yellow	 Yellow / YouTube / Repeat
 Exit	 Exit / Cancel / Clear	 Blue	 Blue / Prime Video / Random
 Scene	 Display / Media	 1	 1
 Internet/Video	 Smart / List	 2	 2





Original		Replacement		Original		Replacement	
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	[≡]		Text / Goto				
	0		0				
	[...]		Subtitle / EQ				
	Vol+		Vol+				
	Prog/CH+		CH+ / Page+				
	Mute		Mute / Dimmer				
	Vol-		Vol-				
	Audio		Audio / Lang I/II				
	Prog/CH-		CH- / Page-				

