












































































	Original	Replacement		Original	Replacement
	Power		Power		[i+]/[?]
	Source		AV		DISPLAY INFO
	[+]		3D		RETURN BACK
	I<<		I<<		ZOOM
	>>I		>>I		TOP MENU MENU
	<<		<<		Up
	>>		>>		Down
	Stop		Stop		Right
	Play		Play		Left
	Pause		Pause		OK
	Red		Red		1
	Green		Green		2
	Yellow		Yellow		3
	Blue		Blue		4
	Repeat		Shift + Text		5
	Audio		Dual		6
	Guide		Guide		7
					8





	Original	Replacement		Original	Replacement
	9	 9			
	0	 0			
	FAV	 +  Shift + Pre Ch			
	[≡]	 Text			
	[...]	 Subt			
	Vol+	 Vol +			
	Vol-	 Vol -			
	Mute	 Mute			
	Prog+	 Ch +			
	Prog-	 Ch -			
	Recall	 Pre Ch			

