



| Original | Replacement |
|---|---|
|  Power |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  Reset |  Guide / EPG / -/-- |
|  0 / AV PC |  0 |
|  RTN |  Back / Return |
|  Display |  Display / Media |
|  Up / P+ |  Up |
|  Up / P+ |  CH+ / Page+ |
|  Input |  AV / Input / RDS |

| Original | Replacement |
|--|---|
|  Left / V- |  Left |
|  Left / V- |  Vol- |
|  Menu / Enter |  Menu / Home |
|  Menu / Enter |  OK |
|  Right / V+ |  Right |
|  Right / V+ |  Vol+ |
|  ARC |  Info / Angle |
|  Down / P- |  Down |
|  Down / P- |  CH- / Page- |
|  Exit |  Exit / Cancel / Clear |
|  Text |  Text / Goto |
|  Text Subcode |  Subtitle / EQ |
|  PIP Up |  Shift + Up |
|  PIP Position |  Shift + Left |
|  PIP On/Off |  Shift + OK |
|  PIP Size |  Shift + Right |
|  PIP Down |  Shift + Down |





| Original | Replacement |
|---|---|
|  Text Reveal |  Play / Slow |
|  Text Index |  Smart / List |
|  Text Hold |  Stop / Hold |
|  Text Cancel |  Rec / Rec Mode |
|  Text Size |  Zoom / Size |
|  Green / MUP |  Green / APP / Repeat |
|  Yellow / Pause |  Yellow / YouTube / Repeat |
|  Yellow / Pause |  Pause / Step / Freeze |
|  Blue / Audio |  Blue / Prime Video / Random |
|  Blue / Audio |  Audio / Lang I/II |
|  Red / Picture |  Red / Netflix / Search |
|  Red / Picture |  Setup / OPT / |
|  Sleep |  Sleep / Timer |
|  Mute |  Mute / Dimmer |
| | |
| | |
| | |
| | |

| Original | Replacement |
|----------|-------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

