






































































Original		Replacement		Original		Replacement	
	Power		Power		PR +		Ch +
	Menu		Menu		PR-		Ch -
	Q.Menu		D. Menu		i		Info
	Exit		Exit		Guide/Tv+Book		Shift + Options
	Back		Back		1		1
	Red		Red		2		2
	Green		Green		3		3
	Yellow		Yellow		4		4
	Blue		Blue		5		5
	OK		Ok		6		6
	Up		Up		7		7
	Down		Down		8		8
	Right		Right		9		9
	Left		Left		0		0
	Mute		Mute		Recall		Pre Ch
	Vol+		Vol +		TV		TV/R
	Vol-		Vol -		[≡]/Text		Text





Original	Replacement	Original	Replacement
 */o..	 Eject		
 Source/Game	 AV		
 */o	 List		
 World	 Guide		
 Music/Movie/Phot	 Options		
 [-O-]	 Sleep		
 [≡]..	 Subt		
 Lang	 Dual		
 Rec	 Rec		
 Stop	 Stop		
 Pause	 Pause		
 Play	 Play		
 >>	 >>		
 <<	 <<		

