



| Original | | Replacement | | Original | | Replacement | |
|----------|--------|-------------|-------------------|----------|----------------|-------------|-----------------------------|
| | Mute | | Mute / Dimmer | | ZAP | | Smart / List |
| | Power | | Power | | Up / P+ | | Up |
| | Prog | | TV/Radio / | | Up / P+ | | CH+ / Page+ |
| | I-II | | Audio / Lang I/II | | Right / Vol+ | | Right |
| | O to O | | Sound / Title | | Right / Vol+ | | Vol+ |
| | PP | | Back / Return | | Left / Vol- | | Left |
| | 1 | | 1 | | Left / Vol- | | Vol- |
| | 2 | | 2 | | Normal | | OK |
| | 3 | | 3 | | Down / P- | | Down |
| | 4 | | 4 | | Down / P- | | CH- / Page- |
| | 5 | | 5 | | Red / Memo | | Red / Netflix / Search |
| | 6 | | 6 | | Green / Audio | | Green / APP / Repeat |
| | 7 | | 7 | | Green / Audio | | Shift + Audio / Lang I/II |
| | 8 | | 8 | | Yellow / Video | | Yellow / YouTube / Repeat |
| | 9 | | 9 | | Blue / Extra | | Blue / Prime Video / Random |
| | 0 | | 0 | | [] | | Display / Media |
| | -- | | Guide / EPG / -- | | [+] | | Stop / Hold |



