



Original	Replacement	Original	Replacement
	Power		Power
	Source		Smart
	List		List
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	AV		AV
	FAV		Pre Ch
	Menu		Menu
	Exit		Exit
	Guide		Guide
	Return		Back
	Info		Info
	Presets		Format
	Up		Up
	Down		Down
	Right/Zoom+		Right
	Left/Zoom-		Left
	OK		Ok
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	PR+		Ch +
	PR-		Ch -
	Red(O) Lang		Red
	Green/Subtitles		Green
	Yellow		Yellow







































Original	Replacement	Original	Replacement
 Blue	 Blue		
 Text/Violet	 Text		
 Stop Text	 Dual		
 ??? Text	 Subt		
 Zoom Text	 Eject		
 Media/Digital	 Media		
 T-Link	 TV/R		
 <<	 <<		
 Play	 Play		
 >>	 >>		
 Rec	 Rec		
 Stop	 Stop		
 Pause	 Pause		





Original	Replacement
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	

Original	Replacement
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	
	





Original	Replacement	Original	Replacement
	Play		Play
	Stop		Stop
	Rec		Rec
	Pause		Pause
	>>		>>
	<<		<<

