



















































Original	Replacement
 Power	 Power
 Sleep	 Sleep
 Dimmer	 Media
 Open/Close	 Eject
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 >10	 Guide
 Repeat	 Text
 Goto	 3D

Original	Replacement
 A-B	 TV/R
 Program	 Shift + Sleep
 Volume+	 Vol +
 Volume-	 Vol -
 Mute	 Mute
 Title	 List
 Menu/PBC	 Menu
 Return	 Back
 Setup	 Options
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Stop	 Stop
 Play	 Play
 Pause	 Pause





	Original	Replacement	Original	Replacement
	<<		<<	
	>>		>>	
	<<		<<	
	>>		>>	
	Language		Dual	
	Subtitle		Subt	
	PAL/NTSC		Format	
	Audio		Shift + Dual	
	Zoom		Shift + Eject	
	Angle		Smart	
	Slow		AV	
	Display		Info	
	Nothing		Pre Ch	

