







































































Original	Replacement	Original	Replacement
	Power		Power
	Red/Sound ↑		Red
	Green/Picture/↓		Green
	Yellow/Feature		Yellow
	Blue/Install		Blue
	[≡]		Text
	[≡0]		Options
	[≡+]		Subt
	[≡x]/[· ·]		Format
	[ /≡]/[*]		Back
	[+](≡♦)/Wide		3D
	[≡?]/PC		Smart
	[≡i]/Guide		Guide
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	P<P		Pre Ch
	-/--		Shift + Guide
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	P+		Ch +
	P-		Ch -
	I-II		Dual
	[i]/Info		Info
	TV/DTV		TV/R
	AV		AV



