


































































































| Original | Replacement | Original | Replacement |
|--|--|--|---|
|  Power |  Power |  Back |  Back / Return |
|  Auto |  Smart / List |  Sleep |  Sleep / Timer |
|  Mute |  Mute / Dimmer |  Aspect |  Shift + Picture / Format |
|  P.Mode |  Picture / Format |  Source |  AV / Input / RDS |
|  S.Mode |  Sound / Title |  Up |  Up |
|  I/II/Audio |  Audio / Lang I/II |  Left |  Left |
|  1 |  1 |  Enter |  OK |
|  2 |  2 |  Right |  Right |
|  3 |  3 |  Down |  Down |
|  4 |  4 |  Red/Eject |  Eject / Surround |
|  5 |  5 |  Red/Eject |  Red / Netflix / Search |
|  6 |  6 |  Green/D.Menu |  D.Menu / Top |
|  7 |  7 |  Green/D.Menu |  Green / APP / Repeat |
|  8 |  8 |  Yellow/Setup |  Yellow / YouTube / Repeat |
|  9 |  9 |  Yellow/Setup |  Setup / OPT / |
|  -/-- |  Shift + Guide / EPG / -/-- |  Blue/D.Disp |  Blue / Prime Video / Random |
|  0 |  0 |  Display |  Display / Media |





| Original | Replacement | Original | Replacement |
|--|--|--|---|
|  Power |  Power |  Back |  Back / Return |
|  Auto |  Smart / List |  Sleep |  Sleep / Timer |
|  Mute |  Mute / Dimmer |  Aspect |  Shift + Picture / Format |
|  P.Mode |  Picture / Format |  Source |  AV / Input / RDS |
|  S.Mode |  Sound / Title |  Up |  Up |
|  I/II/Audio |  Audio / Lang I/II |  Left |  Left |
|  1 |  1 |  Enter |  OK |
|  2 |  2 |  Right |  Right |
|  3 |  3 |  Down |  Down |
|  4 |  4 |  Red/Eject |  Eject / Surround |
|  5 |  5 |  Red/Eject |  Red / Netflix / Search |
|  6 |  6 |  Green/D.Menu |  D.Menu / Top |
|  7 |  7 |  Green/D.Menu |  Green / APP / Repeat |
|  8 |  8 |  Yellow/Setup |  Yellow / YouTube / Repeat |
|  9 |  9 |  Yellow/Setup |  Setup / OPT / |
|  -/-- |  Shift + Guide / EPG / -/-- |  Blue/D.Disp |  Blue / Prime Video / Random |
|  0 |  0 |  Display |  Display / Media |





| Original | Replacement |
|--|--|
|  Exit |  Exit / Cancel / Clear |
|  Menu |  Menu / Home |
|  Vol+ |  Vol+ |
|  Media |  Shift + Display / Media |
|  CH+ |  CH+ / Page+ |
|  Vol- |  Vol- |
|  Rec |  Rec / Rec Mode |
|  CH- |  CH- / Page- |
|  EPG |  Guide / EPG / -/-- |
|  FAV |  Fav / Marker / PC |
|  Subtitle |  Subtitle / EQ |
|  Tv/Radio |  TV/Radio / |
|  Play |  Play / Slow |
|  Text |  Text / Goto |
|  Stop/Index |  Stop / Hold |
|  A-B |  Shift + Yellow / YouTube / |
|  <</Hold |  Shift + Stop / |

Hold

| Original | Replacement |
|---|---|
|  <</Hold |  << / Tune- |
|  >>/Subpage |  >> / Tune+ |
|  Repeat/Reveal |  Shift + Green / APP / |
|  I<</Size |  Zoom / Size |
|  I<</Size |  I<< / Preset- |
|  >>I/Cancel |  Shift + Exit / Cancel / Clear |
|  >>I/Cancel |  >>I / Preset+ |

