



| Original | Rechange |
|----------|-----------------------|
| Power | Power |
| Source | AV / Input / RDS |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |
| 8 | 8 |
| 9 | 9 |
| TV | TV/Radio / |
| 0 | 0 |
| Recall | Shift + Back / Return |
| Vol+ | Vol+ |
| Mute | Mute / Dimmer |
| PR+ | CH+ / Page+ |

| Original | Rechange |
|-----------------|---------------------------|
| Vol- | Vol- |
| World/Internet | Smart / List |
| PR- | CH- / Page- |
| Menu | Menu / Home |
| Q.Menu | D.Menu / Top |
| Up | Up |
| Left | Left |
| OK | OK |
| Right | Right |
| Down | Down |
| Back | Back / Return |
| Exit | Exit / Cancel / Clear |
| i | Info / Angle |
| Camera/Music/Ph | Picture / Format |
| Guide | Guide / EPG / -/- |
| */o | Shift + Guide / EPG / -/- |
| */o.. | Fav / Marker / PC |





| | Original | Recharge | Original | Recharge |
|---|----------|--|----------|-----------------------------|
|  | [≡]/Text |  GOTO TEXT | | Text / Goto |
|  | Red |  NETFLIX SEARCH | | Red / Netflix / Search |
|  | Green |  APP REPEAT | | Green / APP / Repeat |
|  | Yellow |  YouTube REPEAT A-B | | Yellow / YouTube / Repeat |
|  | Blue |  Prime Video RANDOM | | Blue / Prime Video / Random |
|  | Lang |  LANG I/II AUDIO | | Audio / Lang I/II |
|  | [≡].. |  SHIFT + GOTO TEXT | | Shift + Text / |
|  | [-o-] |  OPT-TOOLS SETUP | | Setup / OPT / |
|  | << |  TUNE- | | << / Tune- |
|  | Pause |  STEP-FREEZE | | Pause / Step / Freeze |
|  | >> |  TUNE+ | | >> / Tune+ |
|  | Rec |  REC MODE | | Rec / Rec Mode |
|  | Play |  SLOW | | Play / Slow |
|  | Stop |  HOLD | | Stop / Hold |
| | | | | |
| | | | | |
| | | | | |
| | | | | |

