



























































































Original	Rechange
 Power	 Power
 PBC	 Text / Goto
 Display	 Display / Media
 Eject	 Eject / Surround
 Subtitle	 Subtitle / EQ
 Search	 Red / Netflix / Search
 Angle	 Info / Angle
 Language	 Audio / Lang I/II
 Setup	 Setup / OPT /
 Title	 Sound / Title
 Menu	 Menu / Home
 Zoom	 Zoom / Size
 Resume	 D.Menu / Top
 Up	 Up
 Pause	 Pause / Step / Freeze
 Left	 Left
 OK	 OK

Original	Rechange
 Play	 Play / Slow
 Right	 Right
 Slow	 Shift + Play /
 Down	 Down
 Stop	 Stop / Hold
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 <<	 << / Tune-
 >>	 >> / Tune+
 1/All	 Smart / List
 A-B	 Yellow / YouTube / Repeat
 Vol-	 Vol-
 Vol+	 Vol+
 1	 1
 2	 2
 3	 3
 Mute	 Mute / Dimmer





Original	Rechange	Original	Rechange
	4		4
	5		5
	6		6
	+10		Guide / EPG / -/--
	7		7
	8		8
	9		9
	0		0
	Vocal-Assist		AV / Input / RDS
	Program		TV/Radio /

Original	Rechange

