
































Original	Rechange	Original	Rechange
	Power		Power
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PP		Pre Ch
	[ + ]		Info
	-/Y		Left
	+/>>I		Right
	Menu		Menu
	◇◇		Smart

