































































| Original  |           | Recharge  |        | Original  |             | Recharge  |         |
|---|-----------|---|--------|---|-------------|---|---------|
|    | Power     |    | Power  |    | Vol+        |    | Vol +   |
|    | HDMI1     |    | 1      |    | Vol-        |    | Vol -   |
|    | HDMI2     |    | 2      |    | Mute        |    | Mute    |
|    | HDMI ARC  |    | 3      |    | Voice       |    | Media   |
|    | Coax      |    | Red    |    | Music       |    | Menu    |
|    | Optical   |    | Green  |    | Movie       |    | Info    |
|    | Audio In  |    | Yellow |    | Rear Vol-   |    | 4       |
|    | AUX       |    | Blue   |    | Rear Vol+   |    | 5       |
|    | Bluetooth |    | Smart  |    | Audio Sync- |    | 7       |
|  | I<        |  | I<<    |  | Audio Sync+ |  | 8       |
|  | Play      |  | Play   |  | Night       |  | Options |
|  | Pause     |  | Pause  |  | Auto Vol    |  | Dual    |
|  | >I        |  | >>I    |  | DIM         |  | Subt    |
|  | Bass+     |  | Up     |  | Calibration |  | TV/R    |
|  | Bass-     |  | Down   |   |             |   |         |
|  | Treble+   |  | Ch +   |   |             |   |         |
|  | Treble-   |  | Ch -   |   |             |   |         |

