






































































Original		Rechange		Original		Rechange	
	Power		Power		P+		CH+ / Page+
	TV/R		TV/Radio /		Up		Up
	Source		AV / Input / RDS		Vol+		Vol+
	Mute		Mute / Dimmer		P-		CH- / Page-
	1		1		Left		Left
	2		2		OK		OK
	3		3		Right		Right
	4		4		Vol-		Vol-
	5		5		Down		Down
	6		6		i		Info / Angle
	7		7		Audio		Audio / Lang I/II
	8		8		Sub		Subtitle / EQ
	9		9		Guide		Guide / EPG / -/--
	Exit		Exit / Cancel / Clear		TXT		Text / Goto
	0		0		↔		Fav / Marker / PC
	-/--		Shift + Guide / EPG / -/--		Pause		Pause / Step / Freeze
	Menu		Menu / Home		F1		Shift + 1





Original	Rechange
 Power	 Power
 Tv/R	 TV/Radio /
 Input	 AV / Input / RDS
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Exit	 Exit / Cancel / Clear
 0	 0
 -/--	 Shift + Guide / EPG / -/--
 Menu	 Menu / Home

Original	Rechange
 P+	 CH+ / Page+
 Up	 Up
 Vol+	 Vol+
 P-	 CH- / Page-
 Left	 Left
 OK	 OK
 Right	 Right
 Vol-	 Vol-
 Down	 Down
 i	 Info / Angle
 Audio	 Audio / Lang I/II
 Sub	 Subtitle / EQ
 Guide	 Guide / EPG / -/--
 TXT	 Text / Goto
 ↔	 Fav / Marker / PC
 Pause	 Pause / Step / Freeze
 F1	 Shift + 1



