






































































Original		Rechange		Original		Rechange	
	INFO [i+]/REVEAL [?]		Info / Angle		<		Left
	[+]		Zoom / Size		OK		OK
	POWER		Power		>		Right
	<<		<< / Tune-		RETURN		Back / Return
	PLAY		Play / Slow		V		Down
	PAUSE		Pause / Step / Freeze		Tools		Setup / OPT /
	>>		>> / Tune+		Menu		Menu / Home
	SYNC MENU		D.Menu / Top		RED		Red / Netflix / Search
	STOP		Stop / Hold		GREEN		Green / APP / Repeat
	THEATRE		Picture / Format		YELLOW		Yellow / YouTube / Repeat
	DIGITAL		Display / Media		BLUE		Blue / Prime Video / Random
	ANALOG		Smart / List		1		1
	SUBTITLE [...]		Subtitle / EQ		2		2
	AUDIO		Audio / Lang I/II		3		3
	GUIDE		Guide / EPG / -/--		4		4
	^		Up		5		5
	Source		AV / Input / RDS		6		6





	Original	Recharge	Original	Recharge
	7	 7		
	8	 8		
	9	 9		
	TEXT [=]	 Text / Goto		
	0	 0		
	FAV	 Shift + Fav / Marker / PC		
	VOL+	 Vol+		
	CH+	 CH+ / Page+		
	VOL-	 Vol-		
	CH-	 CH- / Page-		
	MUTE	 Mute / Dimmer		
	RECALL	 Fav / Marker / PC		

