







































































Original	Rechange	Original	Rechange
 Power	 Power	 EPG	 Guide
 Mute	 Mute	 Sat	 Smart
 1	 1	 Exit	 Exit
 2	 2	 Up	 Up
 3	 3	 Prog +	 Ch +
 4	 4	 Down	 Down
 5	 5	 Prog -	 Ch -
 6	 6	 Right	 Right
 7	 7	 Vol +	 Vol +
 8	 8	 Left	 Left
 9	 9	 Vol -	 Vol -
 0	 0	 Ok	 Ok
 Pause	 Pause	 TV / Radio	 TV/R
 Recall	 Back	 Zoom	 Eject
 Fav	 Pre Ch	 Page -	 I<<<
 Menu	 Menu	 Page -	 <<<
 i	 Info	 PIP	 List

Original	Rechange	Original	Rechange
 MUTE	 SHIFT	 TV	 DVD
 SAT	 AUX	 PLAY MODE	 REC MODE
 DUAL	 SUBT	 LEFT	 PAUSE
 SEARCH	 PICTURE	 RIGHT	 STOP
 REPEAT	 ZOOM	 DISC NAV	 SOUND
 TEXT	 AV	 LIST	 AD
 D.MENU	 TIMER	 PROG	 SETTINGS
 TOP MENU	 DISPLAY INFO	 SLEEP	 OPT
 MENU	 INFO	 E-MANUAL	 ECO
 OK	 OK	 TV/R	 3D
 EXIT	 BACK	 D.MENU	 TEXT
 VOL +	 CH +	 REPEAT	 ZOOM
 VOL -	 CH -	 RETURN	 TIMER
 HOME	 SMART	 CLEAR	 BACK
 APP	 MEDIA	 EXIT	 OK
 1	 2	 VOL +	 CH +
 4	 5	 VOL -	 CH -
 7	 8	 HOME	 SMART
 GUIDE	 0	 APP	 MEDIA
A	B	 1	 2
C	D	4	5
Mandis SHOP	www.mandis.tv	7	8
www.mandis.tv	www.mandis.tv	GUIDE	0
www.mandis.tv	www.mandis.tv	FAV	PRE-CH
www.mandis.tv	www.mandis.tv	A	B
www.mandis.tv	www.mandis.tv	C	D
www.mandis.tv	www.mandis.tv	DISC NAV	LIST





Original	Rechange
F1	Options
Page +	>>
Page +	>>
UHF	Format
P/N	3D
TV/SAT	Media
Subtitles	Subt
Red / Audio	Red
Audio	Dual
Green / Mosaic	Green
Yellow / Clock	Yellow
Text	Text
Blue / Text	Blue

Original	Rechange

