






















































	Original	Recharge		Original	Recharge
	Power		Power		Copy
	Mute		Mute		Goto
	Rec		Rec		<<
	Time Shift		Sleep		>>
	Rec List		List		Vol -
	Timer		AV		Vol +
	TV System		TV/R		Play
	1		1		Stop
	2		2		I<<
	3		3		>>I
	4		4		Home
	5		5		Return
	6		6		Return
	7		7		Up
	8		8		Down
	9		9		Right
	0		0		Left



