
























































	Original	Rechange	Original	Rechange
	Power			Media
	Mute			Menu
	1			AV
	2			Exit
	3			Info
	4			Up
	5			Down
	6			Right
	7			Left
	8			Ok
	9			Vol +
	0			Vol -
	ATV/DTV			Rec
	Recall			List
	P.Mode			Tv/Radio
	S.Mode			FAV List
	Sleep			TV/R
				Pre Ch
				Ch +





Original		Rechange		Original		Rechange	
	CH-		Ch -		Cyan		Blue
	Play		Play				
	Pause/Time Shift		Pause				
	<</Guide		<<				
	>>/Aspect		>>				
	Stop/Index		Stop				
	I<</Cancel		I<<				
	>>I/Sub.PG		>>I				
	Freeze		Eject				
	Subtitle		Subt				
	Size		3D				
	Reveal		Options				
	Hold		Smart				
	Text		Text				
	Red		Red				
	Green		Green				
	Yellow		Yellow				

