






Original	Rechange	Original	Rechange
Power	Power	Info	Info
TV/RAD	TV/R	Vol+	Vol +
Bollywood	Format	Vol-	Vol -
[↔]/Ratio	3D	Mute	Mute
Away/Mosquito	Media	FAV	Pre Ch
Source	AV	Guide	Guide
1	1	P+	Ch +
2	2	P-	Ch -
3	3	Back	Back
4	4	Exit	Exit
5	5	Home	Smart
6	6	*	Menu
7	7	Q.Menu	D. Menu
8	8	Text	Text
9	9	T.OPT	Options
0	0	Up	Up
List	List	Down	Down

Original	Rechange	Original	Rechange
Info	Info	Vol +	Vol +
Vol+	Vol +	Vol -	Vol -
Vol-	Vol -	Mute	Mute
Mute	Mute	FAV	Pre Ch
FAV	Pre Ch	Guide	Guide
Guide	Guide	P+	Ch +
P+	Ch +	P-	Ch -
P-	Ch -	Back	Back
Back	Back	Exit	Exit
Exit	Exit	Home	Smart
Home	Smart	*	Menu
*	Menu	Q.Menu	D. Menu
Q.Menu	D. Menu	Text	Text
Text	Text	T.OPT	Options
T.OPT	Options	Up	Up
Up	Up	Down	Down
Down	Down		





Original	Recharge	Original	Recharge
 Right	 Right		
 Left	 Left		
 OK	 Ok		
 AD/*	 Subt		
 Rec	 Rec		
 Stop/Live TV	 Stop		
 <<	 <<		
 Play	 Play		
 Pause	 Pause		
 >>	 >>		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

