





































































Original	Rechange	Original	Rechange
 Power	 Power	 Yellow/V-PP	 Yellow
 Mute	 Mute	 Zoom	 Eject
 1	 1	 A-PP	 Media
 2	 2	 P+	 Ch +
 3	 3	 P-	 Ch -
 4	 4	 Vol+	 Vol +
 5	 5	 Vol-	 Vol -
 6	 6	 Up	 Up
 7	 7	 Down	 Down
 8	 8	 Right	 Right
 9	 9	 Left	 Left
 0	 0	 Menu	 Menu
 -/--	 Guide	 Menu	 Ok
 TV/AV	 AV	 Reveal	 Options
 Green/Timer	 Green	 Size	 Format
 Blue/QV	 Blue	 Mix	 TV/R
 Red/[+]	 Red	 TV/TXT	 Text



