











































| Original | Recharge |
|--|---|
|  Power |  Power |
|  Func |  Menu |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  Mute |  Mute |
|  Sound Effect |  Dual |
|  Optical |  Options |
|  III |  Smart |
|  Repeat |  Text |
|  >>I |  >>I |
|  I<< |  I<< |
|  Play |  Play |
|  Pause |  Pause |
|  Info |  Info |
|  DRC |  Media |
|  Night |  Subt |
|  Auto Vol |  Back |

| Original | Recharge |
|--|---|
|  AV Sync |  AV |
|  Sleep |  Sleep |
|  Auto Power |  Exit |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

