





































































Original		Rechange		Original		Rechange	
	Power		Power		0		0
	Tv/Av		AV		←PR		Back
	Tv/Radio		TV/R		Mute		Mute
	Freeze		Pause		Exit		Exit
	Info		Info		Menu		Menu
	FAV		Pre Ch		EPG		Guide
	[↔]		Format		OK		Ok
	Scan		Smart		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		Red		Red
	5		5		Green		Green
	6		6		Position		3D
	7		7		Yellow		Yellow
	8		8		Text		Text
	9		9		Blue		Blue





Original		Rechange		Original		Rechange	
	Audio		Dual				
	Audio L/R		Subt				
	↑		Ch +				
	↓		Ch -				

