























































	Original	Recharge	Original	Recharge
	Standby			Down
	Rec PVR			Right
	List PVR			Left
	Mute			Ok
	EPG			Vol +
	Audio			Vol -
	Info			1
	DTV/VCR			2
	TTX			3
	Subtitle			4
	Menu			5
	Exit			6
	Favourite			7
	Tv/Radio			8
	CH+			9
	CH-			0
	Up			Recall
				Back









































































	Original	Recharge		Original	Recharge
	Goto	AV			
	<<		<<		
	>>		>>		
	<<		<<		
	>>		>>		
	Play		Play		
	Pause		Pause		
	Stop		Stop		
	Repeat	+ Shift + Text			
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		

	Original	Recharge





Original		Recharge		Original		Recharge	
	Standby		Power		Down		Down
	Rec PVR		Rec		Right		Right
	List PVR		List		Left		Left
	Mute		Mute		OK		Ok
	EPG		Guide		Vol+		Vol +
	Audio		Dual		Vol-		Vol -
	Info		Info		1		1
	DTV/VCR		Media		2		2
	TTX		Text		3		3
	Subtitle		Subt		4		4
	Menu		Menu		5		5
	Exit		Exit		6		6
	Favourite		Pre Ch		7		7
	Tv/Radio		TV/R		8		8
	CH+		Ch +		9		9
	CH-		Ch -		0		0
	Up		Up		Recall		Back





Original		Rechange		Original	Rechange
	Goto		Options		
	<<		<<		
	>>		>>		
	<<		<<		
	>>		>>		
	Play		Play		
	Pause		Pause		
	Stop		Stop		
	Repeat	 + 	Shift + Text		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		

