







































































Original		Rechange		Original		Rechange	
	Power		Power		3D		Shift + 3
	1		1		?		Info / Angle
	2		2		@		D.Menu / Top
	3		3		Menu		Menu / Home
	4		4		Up		Up
	5		5		←		Back / Return
	6		6		Left		Left
	7		7		OK		OK
	8		8		Right		Right
	9		9		Tools		Setup / OPT /
	FAV		Fav / Marker / PC		Down		Down
	0		0		Guide/Home		Guide / EPG / -/--
	TXT		Text / Goto		Guide/Home		Smart / List
	Red		Red / Netflix / Search		Vol+		Vol+
	Green		Green / APP / Repeat		Source		AV / Input / RDS
	Yellow		Yellow / YouTube / Repeat		PR+		CH+ / Page+
	Blue		Blue / Prime Video / Random		Vol-		Vol-



