







































































Original		Rechange		Original		Rechange	
	Power		Power		Mute		Mute
	Source		AV		P+		Ch +
	HDMI		D. Menu		P-		Ch -
	1		1		CH List		List
	2		2		Menu		Menu
	3		3		Guide		Guide
	4		4		Smart Hub		Smart
	5		5		Tools		Options
	6		6		Info		Info
	7		7		Back/Return		Back
	8		8		Exit		Exit
	9		9		Up		Up
	0		0		Down		Down
	TTX/MIX		Text		Right		Right
	PRE-CH		Pre Ch		Left		Left
	Vol+		Vol +		OK		Ok
	Vol-		Vol -		Red		Red





Original		Rechange		Original		Rechange	
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Family Story		Media				
	Search		TV/R				
	P.Size		Format				
	Support		Eject				
	D		3D				
	AD/Subt.		Subt				
	<<		<<				
	I<<		I<<				
	Pause		Pause				
	>>		>>				
	>>I		>>I				
	Rec		Rec				
	Play		Play				
	Stop		Stop				

